

Taking down and packing your Nordic tipi



Before the Nordic tipi is taken down, close the ventilator cap and air intakes.
If there is an inner tent or floor, it does not need to be removed.
Make sure the tent is empty.



Take down the Nordic tipi by releasing the tension on all the ground tensioners and remove the central pole. Close the door and remove all the pegs.



Spread the canvas out on the ground like a fan by folding it once.
Push down a tent peg through the loop at the top of the Nordic tipi.



There are eight fibreglass rods around the smoke opening. Position them in two rows of four (see picture) and then fold once as shown. When you fold up the tent, the canvas that forms the ventilation cap must only be folded once. Otherwise the rods may cause damage.



Using a seam as an edge, stretch the canvas out.
Fold the canvas several times, making sure the fibreglass rods are only folded once.



Use the folded-up central pole as a guide for the correct width. Place the pole on the fibreglass rods. Wrap the canvas tightly around the central pole.



Put a strap around the rolled-up canvas and put it in the packing bag. Compress the bag. On the Safir, Zirkon and flex models, use the strap holders to avoid tangling straps.